# OWNER'S MANUAL KAWASAKI Z900 & RS 287SD-017-150-VAR



## CONTENTS

- Page 2 Introduction/Service
- Page 3-4 Adjustment
- Page 5 Fitting the shock
- Page 6-7 Settings/Notes

# INTRODUCTION

Multiple adjustment, improved control, refinement and awesome looks make K-Tech Razor shocks a leap beyond standard equipment.


The Razor R Lite shock absorbers are available in multiple lengths with 3 way adjustability allowing you to customise your motorcycle for looks and riding style.

- Increased comfort and control
- 3 way adjustability
- Nitrogen Filled (N<sup>2</sup>)
- Anodised black finish
- Optional spring rates

K-Tech Suspension Ltd products are manufactured to fit specific brands and models. Under no circumstances should any K-Tech Suspension Ltd products be fitted to an application other than that for which it has been designed, tested and manufactured.


# **RAZOR SHOCK ABSORBER**

# ADJUSTMENT



#### Rebound damping:-

Bottom Adjuster Wheel:- 32 clicks adjustment range. All settings should be made from the fully closed (Clockwise Position).



#### Spring preload:-


Adjust with collars on the main spring. To adjust, unscrew the top collar (anticlockwise). Then turn the bottom collar to the needed preload (1 turn = 1.5mm).



Then secure by tightening the top collar back onto the bottom collar (clockwise).


# **RAZOR SHOCK ABSORBER**

## ADJUSTMENT



#### Shock length:-

To adjust the shock length loosen the silver lock nut at the bottom of the shock with a 22mm open ended spanner whilst holding the rod joiner (black 22mm hex) with another spanner.




#### Shock length:-

Turn the end eye assembly until you get the desired length.

(1 turn = 1 mm adjustment.)



Make sure you cannot see the groove on the thread.



#### Shock length:-

When you have changed the shock length wind the silver lock nut up to the black rod joiner and torque to 30Nm.

## FITTING THE SHOCK

This procedure should only be carried out by a qualified motorcycle technician. K-Tech Suspension Ltd will not be liable for any damages caused to or by the product, nor be liable for any injuries sustained if the product is fitted by an un-authorised dealer of K-Tech Suspension Ltd. K-Tech Suspension Ltd will not be liable for any damages if the correct tools are not used throughout the entire process of fitting and adjusting the Shock.

Please refer to the manufacturer's workshop manual before attempting this procedure. This procedure will require two people. You will need to remove all relevant bodywork and any other parts that may restrict you from carrying out this task safely.

Place and secure the motorcycle on an appropriate stand so that the wheel is approximately 5cm off the ground. Loosen the top and bottom mounting bolts using the correct spanners. With one person holding the rear wheel in a stationary position the second person can remove the top bolt, it may be necessary to slightly move the rear wheel up and down whilst removing the top bolt. Keeping the rear wheel in a stationary position the second person can now remove the bottom bolt, it will be necessary to hold the shock whilst doing this. Remove the shock from the bike keeping the rear wheel stationary while doing so.

You are now ready to fit the K-Tech Razor shock.

Place the shock into the bike, fitting the bottom mounting bolt first. It may be necessary for the second person to slowly move the rear wheel up or down for you to insert the bolt through any linkages.

Fit the top mounting bolt and torque both top and bottom bolts to the manufacturer's recommendations.

To attach the remote reservoir, remove the left-hand pillion footrest hanger and fit the reservoir bracket in between the hanger and the frame. Re-use the original screws for the footrest hanger and torque to manufacturer's recommendations.

#### Take a slow test drive to make sure that everything is correct.

### SETTINGS

RECOMMENDED:	
Shock length	<b>351</b> (+10/-0 )mm
Shock stroke	75mm
Reb damping	16 Clicks Out
Gas Pressure	12 bar

PART No.	SPRING	RATE N/mm	PRELOAD
287SD-017-150-089	46-180-100	100	13mm
287SD-017-150-090	46-180-110	110	12mm
287SD-017-150-091	46-180-120	120	11mm
287SD-017-150-092	46-180-130	130	10mm

## SERVICE

K-Tech Suspension Ltd recommend that this product is serviced every 10,000 miles of use. It is very important that this product is serviced by an authorised dealer, as there are special tools required to guarantee correct performance of this product. K-Tech Suspension Ltd cannot be held responsible for any damage caused to/by the product if a service is overdue or was not conducted by an authorised dealer.

www.ktechsuspension.com/service-centres-and-partners

# RAZOR SHOCK ABSORBER



# www.ktechsuspension.com

Contact your local K-Tech dealer for more details at www.ktechsuspension.com/service-centres-and-partners